

SANIWERKE LOUNGE HAMMOCK

(Double)

Using Instructions of foothold



- Warning:
- * Do not attempt to use the foothold as a seat.
 - * Chair Wooden and rope will not support excessive weight.
 - * Do not allow small children to play in this chair unattended.


Step 1: Adjust your chair to the proper height and angle of recline.

Step 2: Hang the foothold from the same hook that the chair is suspended from.

Step 3: Using the blocks, adjust the foothold such that it will slide under the chair and the frame of the foothold is parallel to the floor.

To use the foothold, sit in the chair. Reach outside the frame and between front and back suspension ropes. Lift in the direction 'A' and push in direction 'B' (as illustrated) while lifting your feet. Hook your heels on the foothold; push out until foothold is supporting your feet and lower legs.

To return the foothold to the stowed position simply lift your feet, push down on the open end of the frame and let it swing back under the chair seat. The foothold stores neatly under the chair when not in use.



SANIWERKE LOUNGE HAMMOCK

(Double)


Hanging Instructions




Warning: Please read and follow these installation instructions, DO NOT exceed the maximum load limit of 420LB. DO NOT let small children play in the chair unattended. After installation, periodically verify that the screw hook is secure.

Location: You will need to satisfy two considerations: First, a sturdy anchor point overhead about 4-ft. wide, (for the two screw hooks). Nothing less than 2" x 6" framing lumber should be used. Second, you will need space below for the chair to occupy. Roughly the same size that a love-seat or similar piece of furniture would require: An area of approximately 5-feet by 6-feet.

Install the hooks: Using an electric drill with a 5/16" drill bit very carefully locate the center of the overhead beam. Drill a hole straight-up (plumb) about 2" deep. Install the hook; be sure to bury all the threads. DO NOT install the hook horizontally!



DO NOT adjust chair while someone is in it



To adjust the chair hold the block in one hand and slide the rope up or down with the other hand

Hang and adjust the chair: Hang the chair from the hooks and slide the adjusting blocks down the support ropes until the chair is level, the correct height from the floor, and reclined to suit your needs, Toss the cushions in and have a seat. Make further adjustments as necessary for height and angle of recline.

Care and maintenance: Spot clean the pillows. Clean the ropes using warm, soapy water and a soft bristled scrub brush. Rinse thoroughly and allow to dry completely, preferably in direct sunlight. To spruce up the wood frame, carefully apply furniture oil using a soft, clean cloth. DO NOT store this chair where mice or bugs may be present.

